

Getting Started

The information in this chapter will enable you to:

- Verify that each component of your system has been delivered safely
- Properly configure and *check out* the system

What You Should Have

Inspect your ZX shipment upon receipt for obvious damage to its shipping container. Report any damage to the shipping company immediately. Compumotor cannot be held responsible for damage incurred in shipment.

Part/Quantity	Available Types
ZX or ZXF Drive Motor	ZX600 (120VAC or 240VAC) or ZX900 (240VAC) ZX605, ZX606, ZX610, ZX620, ZX630, ZX640, ZX805, ZX806, ZX810, ZX820, ZX830, ZX840, ZX910, ZX920, ZX930, or ZX940
Motor Cable	25 ft., 50 ft., or 100 ft.
Resolver Cable	25 ft., 50 ft., or 100 ft.
ZX Drive User Guide	88-011631-01 D
ZX Software Reference Guide	88-011798-01 E

Ship Kit (ZX System)


Part/Quantity	Available Types
ZX Drive or ZXF (1)	ZX600 (120VAC or 240VAC) or ZX900 (240VAC)
ZX Drive User Guide	88-011631-01 D
ZX Software Reference Guide	88-011798-01 E

Ship Kit (ZX Indexer/Drive Only)


Drive/Motor Configuration

Compumotor configures ZXs according to the motor that you order. *If you purchased the ZX to run 600 Series motors (ZX605, ZX606, ZX610, ZX620, ZX630, and ZX640), it will not run 800 Series (ZX805, ZX806, ZX810, ZX820, ZX830, and ZX840) or ZX900 series motors (ZX910, ZX920, ZX930, and ZX940). All ZX Series drives **must** be run with the same ZX Series motors.* You can determine which motor you have by checking the model numbers on the drive and motor labels.

The ZX600 and ZX800 are available in a **120VAC version** and a **240VAC version**. The ZX900 Drive is available in a **240VAC** version only.



ZX600/ZX800 Bench Test



ZX900 Bench Test


Tools

To complete the Check-Out Procedure, you must have the following tools:


- Phillips-head screwdriver
- Large flat blade screwdriver
- Small flat blade screwdriver
- Power cable

Step ①

Connect the resolver cable between the ZX I/O [2] connector and the servo motor as shown in the following figures (for ZX600/ZX800 or ZX900).



ZX600/800 Resolver Cable Connection




ZX900 Resolver Cable Connection

Step ②


Connect the cable between the ZX motor connector and the servo motor. *Match the color of the wire with the proper terminal.*

WARNING

Never disconnect the motor cable with the power on. The motor produces lethal voltages. Be sure the motor is properly grounded to reduce the chance of electrical shock.



ZX600/800 Motor Cable Connection




ZX900 Motor Cable Connection


Step ③

Measure and verify your incoming 3-phase 240VAC (or 120VAC) line with a voltmeter. Connect, **but do not energize**. The ZX is designed to operate best on a balanced 3-phase input. Additional wiring options for this connection are provided in *Chapter ③ Installation*.

WARNING
Be sure the drive is properly grounded to reduce the chance of electrical shock.



ZX600/800 Power Cable Connection




ZX900 Power Cable Connection

Step ④

Connect a terminal to the RS-232C connector (I/O[1]) using the **Rx** (receive), **Tx** (transmit), and **G** (ground) connections. The basic communications parameters are listed below:

- Baud Rate: 9600
- Parity: None
- Data Bits: 8
- Full Duplex mode
- Stop Bits: 1

Refer to the operations manual that accompanied your terminal for instructions on setting the communication parameters listed above. **Chapter ③ Installation** provides detailed RS-232C information for the ZX.



RS-232C Connection

Be sure that the ZX's **ENBL** input (**I/O [1]**) is jumpered to ground. The ZX is shipped with the **ENBL** input grounded.

If you use a host computer to send characters to the ZX via RS-232C at a high rate, you may need to insert time delays (*spacing characters*) to ensure that the ZX has enough time to process each character. The ability to set a variable time delay is available in most terminal emulator packages.

Step ⑤ **Apply power to all system components now.** The following response should appear on the terminal:

```
*READY
>
```

The following response should appear on the ZX's 4-digit display:

OK

Step ⑥ You must now disable the hardware limits. Type the following command to disable the limits: > LD3

To check the LD state of your hardware limits command, enter the following command: > 1LD

You should receive the following response: *3_No_Limits_Enabled

Step ⑦ Enter the following commands to move the motor 25,000 steps.

Command	Description
> A10	Sets acceleration to 10 rps ²
> AD10	Sets deceleration to 10 rps ²
> V1	Sets velocity to 1 rps
> D25000	Sets distance to 25,000 steps
> G	Initiates motion

Since the default drive resolution is 5,000 steps/rev, the motor should have moved 25000 steps or 5 revolutions.

This completes the basic configuration tests. The successful completion of this test means that you wired the resolver, motor, terminal (optional), and power connections correctly. The components of your system are functioning properly. If the motor does not move as commanded, check your connections and try the test again. In Chapter ③ you will install and test the rest of your system's components.

ZXF Option

The ZXF can be used as an indexer. However, the ZX cannot perform following functions. The ZXF is configured as an indexer when you receive it from the factory. You can use software commands to enter or exit the Following mode. In *Chapter ③ Installation*, encoder installation and use of the Following mode are explained. *Chapter ④ Application Design* provides some practical examples of Following mode operation.