

## Software Reference

The information in this chapter will enable you to:


- Understand the Z Drive's command language
- Use this chapter as a reference for the function, range, default, and sample use of each command

The Z Drive has more than 40 software commands that you can use to tune the drive, define various parameters, and display drive variables. All commands are sent to the drive over the RS-232C serial interface. Any terminal or computer that has an RS-232C port can communicate with the Z Drive. *Chapter ③ Installation* explains the configuration of the RS-232C port. *Chapter ⑧ Maintenance & Troubleshooting*, offers guidelines to help you resolve communications problems.

### Command Format Description

---

The following section describes the format of the command descriptions used in this chapter. The numbered arrows refer to the numbered sections below the drawing.



**① Command Identifier**

The letter or letters used to represent the command.

**② Command Name**

This name used to refer to the command. For example, Acceleration for the A command.

### ③ Version

The revision of software in the Z Drive when the described command was first introduced or last modified. If the revision level of the software you are using is equal to or greater than the revision level listed here, the command is available in your unit. You can determine the level of software in your Z Drive by issuing the Revision Level (RV) command.

### ④ Characteristics

The following sections describe the main characteristics of the command.

#### Type

This portion of the box contains the command's type. The four command types are listed below.

#### Set-Up

These commands define Set-Up conditions for the application. Set-Up commands include the following types of commands:

- Homing (go home acceleration and velocity, etc.)
- Input/Output (limits, scan time, in-position time, etc.)
- Tuning (servo or position tracking)
- General (set switches, return to factory settings, etc.)

#### Programming

Programming commands affect programming and program flow. For example, trigger, output, all sequence commands, quote, time delays, pause and continue, enable and front-panel, loop and end loop, line feed, carriage return, and backspace.

#### Status

Status commands respond (report back) information.

#### Motion

Motion commands affect motor motion (for example, acceleration, velocity, distance, go home, stop, direction, mode, etc.)

#### Syntax

This field shows the syntax for the command. Z Drive commands use the following generic syntax: `acspd`.

|                   |  |
|-------------------|--|
| Variable <b>a</b> | This variable is the device address. If the address is optional it is shown in angle brackets: <d>. Only commands which require the Z Drive to send a response require a device address. All commands may use a device address to designate which unit on a daisy chain the command is intended for. |
| Variable <b>c</b> | This variable is the command identifier, which is one or more letters.   |
| Variable <b>s</b> | This variable represents a sign. A sign is not allowed for all commands. The <b>s</b> is not shown in the syntax if not allowed.   |
| Variable <b>p</b> | This variable represents the parameters the command requires. There may be zero or more parameters. If the number of parameters is zero <b>n</b> is not shown in the syntax.   |
| Variable <b>d</b> | This variable is the end of command delimiter. This is always required and is not shown in the following descriptions for clarity. The delimiter may be a space character or a carriage return.  |

#### Units

This field describes what unit of measurement the parameter in the command syntax represents.

#### Range

This is the range of valid values that you can specify for **n** (or any other parameter specified).

#### Default

The default setting for the command is shown in this box. A command will perform its function with the default setting if you do not provide a value.

#### Response

The response to the command is shown in this box. Status commands report a condition in the indexer. Status commands do not affect the status they read.

Commands that set parameters report the parameters when the command is issued without a parameter. For example, `A100` sets the acceleration to 100 rps, but `1A` returns the current setting. **Note:** *To receive a response, a device address is required.*

#### See Also

Commands that are related or similar to the command described are listed here.

### ⑤ Attributes

Each command has attributes as shown below.

**Attributes**

- Buffered
- Device specific
- Independently saved
- Saved in sequences

**Buffered**

If the Buffered box is checked the command is buffered. If it is not checked the command is acted on immediately. Buffered commands are executed in the order they are received. An internal buffer, or storage area, holds the commands in a queue until the previous command has been executed.

Immediate commands are executed as they are received. Immediate commands are executed even if the command buffer has commands in it. For example, the Stop (s) command is immediate. When a Stop command is received the motor is stopped as soon as the command is received. The Z Drive does not process the commands in its command buffer before stopping the motor.

**Device Specific**

If the Device specific box is checked the command requires a device identifier. If it is not checked the command may be used with or without a device identifier. Commands which are device specific are normally Status commands. Device specific commands have a syntax description with a *d* by itself before the command. If it is not device specific the command syntax description has a *<d>* in angle brackets before the command.

**Saved Always**

If the Independently saved box is checked the parameter controlled by the command is always saved. This differs from commands which may only be saved in sequences and those which are never saved. If neither the Saved always nor the Saved in sequences box is checked the command is never saved.

**Saved In Sequences**

If the Saved in sequences box is checked the command will be saved only if it is in a sequence and you issue the Save command (sv). If neither the Saved always nor the Saved in sequences box is checked the command is never saved.

⑥ **Description**

A description of the command appears in this area along with any special considerations you should know about.

⑦ **Example**

An example of how to use the command appears in this area. The left column contains the commands you would issue to the Z Drive. The right column contains descriptions of what the commands do in the program.

# Command List

| <b>Command</b> | <b>Tuning Commands</b>                  |
|----------------|---|
| CPD            | Configure Position Derivative           |
| CPDM           | Configure Position Derivative Maximum   |
| CPI            | Configure Position Integral             |
| CPIM           | Configure Position Integral Maximum     |
| CPP            | Configure Position Proportional         |
| CPPM           | Configure Position Proportional Maximum |
| CTC            | Configure Time Constant                 |
| CTG            | Configure Tach Gain                     |
| CTGM           | Configure Tach Gain Maximum             |
| CVF            | Configure Velocity Feed-Forward         |
| CVFM           | Configure Velocity Feed-Forward Maximum |
| CVI            | Configure Velocity Integral             |
| CVIM           | Configure Velocity Integral Maximum     |
| CVP            | Configure Velocity Proportional         |
| CVPM           | Configure Velocity Proportional Maximum |

| <b>Command</b> | <b>Drive Commands</b>                 |
|----------------|---------------------------------------|
| CCA            | Configure Current Average             |
| CCP            | Configure Current Peak                |
| CDB            | Configure Deadband                    |
| CIP            | Configure In Position                 |
| CMR            | Configure Motor Resolution            |
| CMV            | Configure Max. Velocity (Torque Mode) |
| CMTR           | Configure Motor Type                  |
| CPE            | Configure Position Error              |
| CRR            | Configure Resolver Resolution         |
| CVE            | Configure Velocity Error              |

| <b>Command</b> | <b>Display Commands</b>       |
|----------------|-------------------------------|
| DCA            | Display Current Average       |
| DCI            | Display Current Instantaneous |
| DCP            | Display Current Peak          |
| DDI            | Display Drive Information     |
| DPA            | Display Position Actual       |
| DPE            | Display Position Error        |
| DPR            | Display Position Resolver     |
| DPS            | Display Position Setpoint     |
| DSP            | Display Servo Picture         |
| DVA            | Display Velocity Actual       |
| DVE            | Display Velocity Error        |
| DVS            | Display Velocity Setpoint     |

| <b>Command</b> | <b>Miscellaneous Commands</b>    |
|----------------|----------------------------------|
| CPB            | Configure Pushbuttons            |
| CZM            | Configure Z Drive Mode           |
| DISP'          | Front Panel Display              |
| E              | Enable Communications Interface  |
| F              | Disable Communications Interface |
| FMCA           | Find Motor Commutation Angle     |
| ^H             | Backspace                        |
| HELP           | Help                             |
| OFF            | Amplifier Off                    |
| ON             | Amplifier On                     |
| OUT            | Real Time Output Control         |
| RFS            | Return to Factory Settings       |
| RSE            | Report Servo Errors              |
| RV             | Revision Level                   |
| SS             | Set-up Status Report             |
| SSA            | RS-232C Echo Control             |
| SSI            | Interactive Mode Control         |
| SSM            | Direction Input Polarity Control |
| SSR            | Analog Output Control            |
| SSU            | Set Warning Display Mode         |
| SV             | Save                             |
| Z              | Reset                            |

| <b>Command</b> | <b>Analog Voltage Commands</b> |
|----------------|--------------------------------|
| ANDB           | Analog Voltage Deadband        |
| ANG            | Analog Voltage Gain            |
| ANV            | Analog Voltage Range           |
| ANZ            | Analog Voltage Zero            |

# Alphabetical Command List

## ANDB Analog Voltage Deadband

Version A

**Type** Set-Up  
**Syntax** <a>ANDBn  
**Units** n = volts  
**Range** 0.00 - 1.00  
**Default** 0.00  
**Response** \*ANALOG\_DEADBAND=nnn.nn\_VOLTS  
**See also** ANV, ANZ

**Attributes**  
 [ ] Buffered  
 [ ] Device specific  
 [ ] Saved independently  
 [ ] Saved in sequences

ANDB defines the maximum analog voltage deadband that the Z Drive will allow without commanding torque to the motor. This voltage should normally be zero to allow for the greatest command accuracy. If your application requires zero velocity drift, a deadband may be required.

| Command    | Description                        |
|------------|------------------------------------|
| > ANDB0.10 | Sets the analog deadband to 100 mV |


## ANG Analog Voltage Gain

Version C

**Type** Set-Up  
**Syntax** <a>ANGn  
**Units** n = mode  
**Range** 1 or 2  
**Default** 1  
**Response** \*ANALOG\_GAIN=1  
**See also** ANV

**Attributes**  
 [ ] Buffered  
 [ ] Device specific  
 [ ] Saved independently  
 [ ] Saved in sequences

This command offers two different analog input voltage to desired velocity (or torque) relationships. ANG1 use a linear function (see ANV command). ANG2 uses a parabolic function (refer to the following figure).



ANG Graphical Relationship

## ANV Analog Voltage Range

Version A

**Type** Set-Up  
**Syntax** <a>ANVn  
**Units** n = rpm or amp  
**Range** Motor dependent  
**Default** Motor dependent  
**Response** \*10V\_ANALOG=nnnnn\_RPM  
 \*10V\_ANALOG=nn.nn\_AMPS  
**See also** ANDB, ANZ, CZM, ANG

**Attributes**  
 [ ] Buffered  
 [ ] Device specific  
 [ ] Saved independently  
 [ ] Saved in sequences

This command defines the ratio between the input voltage range and the commanded velocity or torque. Once the ANV value is specified, the desired speed or torque is calculated as follows (assuming ANG = 1):

$$\text{Desired speed or torque} = \left( \frac{\text{Input voltage}}{10V} \right) * \text{ANV Setting}$$

First, verify the drive's the operational mode. Use the Configure Z Drive Mode (CZM) command before using ANV. While in Velocity mode (CZM3) the ANV default is set so that 10V equals the rated speed of the motor. While in Torque mode (CZM2), the ANV default is set so that 10V equals the rated continuous torque of the motor. The value can be set as high as the peak allowable torque. If an application requires greater analog input resolution for low speeds or low torques, use ANV to set 10V equal to a lower speed or torque value.

| Command   | Description                              |
|-----------|--|
| > CZM3    | Sets the Z Drive to velocity mode        |
| > ANV1000 | Sets 10V analog input equal to 1,000 rpm |

## ANZ Analog Voltage Zero

Version A

**Type** Set-Up  
**Syntax** <a>ANZ  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** ANV, ANDB

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command executes the Analog Auto Zero feature. Execute this command to set the current voltage level to represent 0V. This command is used to remove the DC offset out of the commanded velocity (or torque). If this command is not used, a small offset in the servo controller will cause the motor to creep.

| Command | Description                          |
|---------|--------------------------------------|
| > ANZ   | Defines the analog input value as 0V |

## CCA Configure Current Average

Version A

**Type** Set-Up  
**Syntax** <a>CCAn  
**Units** n = amperes  
**Range** Motor and Drive dependent  
**Default** Motor dependent  
**Response** \*AVE\_CURRENT\_LIMIT=nnn.nn\_AMPS  
**See also** CCP

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the maximum average current. If the average current commanded by the controller exceeds the value defined by CCA command, the amplifier will be disabled.

| Command    | Description   |
|------------|---|
| > CCA20.00 | Sets the average current limit to 20.00A (14.14 Arms) |

## CCP Configure Current Peak

Version A

**Type** Set-Up  
**Syntax** <a>CCPn  
**Units** n = amperes  
**Range** Motor and Drive dependent  
**Default** Motor dependent  
**Response** \*PEAK\_CURRENT\_LIMIT=nnn.nn\_AMPS  
**See also** CCA

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the maximum peak current that will be sent to the motor. The commanded current will never exceed the value defined by the CCP command.

| Command    | Description  |
|------------|--|
| > CCP40.00 | Sets the peak current limit to 40.00A (28.28 Arms) |

## CDB Configure Deadband

Version A

**Type** Set-Up  
**Syntax** <a>CDBn  
**Units** n = steps  
**Range** 0 - (1048575)  
**Default** 0  
**Response** \*SLIP\_FAULT\_DEADBAND=nnnnnnn\_STEPS  
**See also** CIP, CMR, CPE

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

The CDB command defines the deadband in steps. The deadband is the range of input signals for which there is no system response. If the absolute value of the position error exceeds the deadband, the in-position output on the Indexer Connector will be active. When the In-Position line is off, the absolute value of the position error is within the deadband region (for the minimum time specified by the Configure In-Position (CIP) command. This command is scaled by the Configure Motor Resolution (CMR) command (steps are in the user's resolution). Set the desired CMR value before setting the CDB value.

CDB differs from the Configure Position Error (CPE) command. When the deadband is exceeded, the In-Position signal on the indexer connector will be activated, but the drive will continue to strive for zero position error. When the position error limit is exceeded, the drive will fault.

| Command | Description                   |
|---------|-------------------------------|
| > CDB50 | Sets the deadband to 50 steps |

## CIP

## Configure In-Position

Version A

**Type** Set-Up  
**Syntax** <a>CIPn  
**Units** n = 5 ms increments  
**Range** 0 - 255  
**Default** 0  
**Response** \*IN\_POSITION\_TIME=nnn (\*5\_milliSeconds)  
**See also** CDB

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

The CIP command defines the minimum time for the motor to be declared *in-position*. This command is used in conjunction with the Configure Deadband (CDB) command. The deadband is the range of input signals for which there is no system response. The CIP command specifies the amount of time required within the deadband to activate the in-position output. When the in-position line is off, the absolute value of the position error has been within the deadband region for the minimum time specified by the CIP command.

| Command | Description                                 |
|---------|---|
| > CIP10 | Sets the in-position time to 10*5ms = 50 ms |

## CMR

## Configure Motor Resolution

Version A

**Type** Set-Up  
**Syntax** <a>CMRn  
**Units** n = steps  
**Range** 200-32768 (Any #), 32768-65536 (even #'s only)  
**Default** 5000  
**Response** \*MOTOR\_RESOLUTION\_(STEPS)=nnnn  
**See also** OFF, ON

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

The CMR command defines the resolution of the motor in steps per revolution. This resolution will be used when interpreting the step input from the indexer.

This command changes the values and responses of the CPE, CDB, DPA, and DPE commands. You should configure motor resolution before you use any of these commands. Before you define the resolution, you must issue the OFF command to shut down the drive. After the CMR command is executed, you must issue the ON command to re-enable the drive.

Changing motor resolution does not affect the system's performance. The controller converts the commanded position to the proper absolute resolver position.

| Command   | Description                                 |
|-----------|---|
| > OFF     | Turns amplifier off                         |
| > CMR4096 | Defines motor resolution of 4,096 steps/rev |
| > ON      | Turns amplifier on                          |

## CMTR

## Configure Motor

Version A

**Type** Set-Up  
**Syntax** <a>CMTRn  
**Units** n = motor type  
**Range** 605, 606, 610, 620, 630, 635, 640, 805, 806, 810, 820, 830, 840, 910, 920, 930, 940  
**Default** 605  
**Response** \*MOTOR\_TYPE=Znnn  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

Use this command to configure the drive to the motor size that is being used. The drive is configured at the factory, but if you change motor size, you must reconfigure the motor type.

This command selects the proper current values and factory defaults for the various motor sizes that may be used with the drive. Issuing the CMTR command will return the following set-up parameters to their default values: ANV, CCA, CCP, CPD, CPDM, CPI, CPIM, CPP, CPPM, CRR, CTC, CTG, CTGM, CVE, CVF, CVFM, CVI, CVIM, CVP, CVP, and motor commutation data. CMTR automatically saves these parameters.

| Command   | Description  |
|-----------|--|
| > CMTR620 | Configures drive for default settings for the Z620 motor |

## CMV Configure Maximum Velocity

Version A

**Type** Set-Up  
**Syntax** <a>CMVn  
**Units** n = rpm  
**Range** 0 - 7000  
**Default** Motor dependent  
**Response** \*MAX\_VELOCITY\_(TORQUE\_MODE\_ONLY)=nnnn\_RPM  
**See also** CZM

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

Use **CMV** only when operating in Torque mode (**CZM2**). **CMV** limits maximum motor speed in Torque mode.

| Command | Description   |
|---------|---|
| > CMV32 | Configures drive for maximum velocity of 32 rpm when in Torque mode |

## CPB Configure Pushbuttons

Version A

**Type** Set-Up  
**Syntax** <a>CPBn  
**Units** n = pushbuttons  
**Range** 0 = disabled, 1 = enabled, 2 = chgs disabled  
**Default** 1  
**Response** \*CPB=2...BUTTON\_CHANGES\_DISABLED  
\*CPB=1...BUTTONS\_ENABLED  
\*CPB=0...BUTTONS\_DISABLED

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

**See also** None

This command controls user access to the front panel pushbuttons. Since many drive parameters can be modified via the front panel, it may be desirable to disable this interface.

- CPB0** = All pushbutton functionality is disabled.
- CPB1** = Pushbuttons are enabled.
- CPB2** = Pushbuttons are partially enabled—display features are enabled. Parameter/drive modifications are disabled.

| Command | Description              |
|---------|--------------------------|
| > CPB0  | Pushbuttons are disabled |

## CPD Configure Position Derivative

Version A

**Type** Set-Up  
**Syntax** <a>CPDn  
**Units** n = % of maximum derivative gain  
**Range** 0 - 99  
**Default** Motor dependent  
**Response** \*POSITION\_DERIVATIVE\_PERCENT=nn  
**See also** CPDM (Refer to *Chapter 4 Application Design* for tuning information.)

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

**CPD** defines the derivative gain for the position control loop. When you tune the drive using **CPD**, a percentage of the Configure Position Derivative Maximum (**CPDM**) is set. **CPD** overrides the Configure Velocity Feed-Forward (**CVF**) and Configure Tach Gain (**CTG**) commands.

| Command | Description   |
|---------|---|
| > CPD15 | Sets position derivative gain to 15% of the maximum value |

## CPDM Configure Position Derivative Maximum

Version A

**Type** Set-Up  
**Syntax** <a>CPDMn  
**Units** n = maximum derivative gain  
**Range** 0 - 32767  
**Default** Motor dependent  
**Response** \*POSITION\_DERIVATIVE\_MAXIMUM=nnnn  
**See also** CPD

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

**CPDM** defines the maximum derivative gain for the position control loop. When tuning the drive, set **CPDM** and adjust the overall derivative gain parameter by increasing or decreasing the **CPD** value. **CPDM** is configured at the factory and typically does not need to be adjusted. (Refer to Display Drive Information [**DDI**] example.)

| Command    | Description                                   |
|------------|---|
| > CPDM1000 | Sets maximum derivative gain to 1,000         |
| > CPD15    | Sets position derivative gain to 15% of 1,000 |

## CPE Configure Position Error

Version A

**Type** Set-Up  
**Syntax** <a>CPEn  
**Units** n = steps  
**Range** 0 - 1048575  
**Default** 5000  
**Response** \*POSITION\_ERROR\_LIMIT=nnnnnn\_STEPS  
**See also** CMR

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command specifies a value for the maximum position error. If the position error exceeds the CPE value, the controller will disable the amplifier. CPE is scaled by the Configure Motor Resolution (CMR) command (steps are in the user's resolution). Set the desired CMR value before setting the CPE value. CPE0 will disable the position error fault.

CPE differs from the Configure Deadband (CDB) command. When the deadband is exceeded, the in-position signal on the indexer connector will be activated, but the drive will continue to strive for zero position error. When the position error limit is exceeded, the drive will fault.

| Command   | Description  |
|-----------|--|
| > CPE1000 | Sets the maximum position error to 1,000 motor steps |

## CPI Configure Position Integral

Version A

**Type** Set-Up  
**Syntax** <a>CPI n  
**Units** n = % of maximum integral gain  
**Range** 0 - 99  
**Default** Motor dependent  
**Response** \*POSITION\_INTEGRAL\_PERCENT=nn  
**See also** CPIM

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the integral gain for the position control loop. When you tune the drive using the CPI command, you are setting a percentage of the Configure Position Integral Maximum (CPIM).

| Command | Description  |
|---------|--|
| > CPI5  | Sets position integral gain to 5% of the maximum value |

## CPIM Configure Position Integral Maximum

Version A

**Type** Set-Up  
**Syntax** <a>CPIMn  
**Units** n = maximum integral gain  
**Range** 0 - 32767  
**Default** Motor dependent  
**Response** \*POSITION\_INTEGRAL\_PERCENT=nn  
**See also** CPI

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the maximum integral gain for the position control loop. When tuning the drive, first set CPIM and then adjust the overall derivative gain parameter by increasing or decreasing CPI. CPIM is configured at the factory and typically does not need to be adjusted. Refer to the Display Drive Information (DDI) command example.

| Command   | Description                                |
|-----------|--|
| > CPIM500 | Sets maximum integral gain to 500          |
| > CPI5    | Sets position derivative gain to 5% of 500 |

## CPP Configure Position Proportional

Version A

**Type** Set-Up  
**Syntax** <a>CPPn  
**Units** n = % of maximum proportional gain  
**Range** 0 - 99  
**Default** Motor dependent  
**Response** \*POSITION\_PROPORTIONAL\_PERCENT=nn  
**See also** CPPM

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the proportional gain for the position control loop. When you tune the drive using the CPP command, you are setting a percentage of the Configure Position Proportional Maximum (CPPM).

| Command | Description   |
|---------|---|
| > CPP35 | Sets position proportional gain to 35% of the maximum value |

## CPPM Configure Position Proportional Maximum

Version A

**Type** Set-Up  
**Syntax** <a>CPPMn  
**Units** n = maximum proportional gain  
**Range** 0 - 32767  
**Default** Motor dependent  
**Response** \*POSITION\_PROPORTIONAL\_MAXIMUM=nnnn  
**See also** CPP

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the maximum proportional gain for the position control loop. When you tune the drive, you must first set CPPM and then adjust the overall derivative gain parameter by increasing or decreasing the CPP. CPPM is configured at the factory and typically does not need to be adjusted. Refer to the Display Drive Information (DDI) command example.

| Command    | Description                                     |
|------------|---|
| > CPPM2500 | Sets maximum to 2,500                           |
| > CPP35    | Sets position proportional gain to 35% of 2,500 |

## CRR Configure Resolver Resolution

Version A

**Type** Set-Up  
**Syntax** <a>CRRn  
**Units** n = bits or auto (A)  
**Range** 12, 14, 16, A  
**Default** A for position or torque mode, n for Velocity mode  
**Response** \*RESOLVER\_RESOLUTION=AUTO  
\*RESOLVER\_RESOLUTION=nn\_BITS...[nnnn\_RPM\_MAX]  
**See also** DPR

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

The CRR command defines the resolution of the resolver. The resolver provides information required by the controller to commutate the motor and perform its servo loop. This number is expressed in bits. Higher resolutions are desirable, but limit the speed at which the resolver to digital converter can operate. The following is the maximum speed for each resolution setting:

- 12-bits = 4,096 counts/rev 7000 rpm max
- 14-bits = 16,384 counts/rev 3800 rpm max
- 16-bits = 65,536 counts/rev 900 rpm max

*If the velocity commanded by the indexer exceeds these maximum values, the amplifier will be disabled.*

The CRR command selects automatic resolution switching. In this mode, the Z Drive chooses the highest resolution, based on the present motor speed. This is desirable for most applications. Do not use the CRR command if you are using the pseudo-quadrature outputs (refer to [Chapter 4 Application Design](#)).

| Command | Description                                  |
|---------|--|
| > CRR12 | Sets resolver resolution to 4,096 counts/rev |

## CTC Configure Time Constant

Version A

**Type** Set-Up  
**Syntax** <a>CTCn  
**Units** n =  $\mu$ Sec  
**Range** 0 - 30000  
**Default** Position mode = 5, Velocity mode = 5 Torque mode = 20  
**Response** \*TIME\_CONSTANT=nnnn>(\*100\_microSeconds)  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the filter time constant of the servo loop in increments of 100  $\mu$ s periods, where 100  $\mu$ s is the servo update rate. The CTC command controls the -3dB frequency of the torque command's low-pass filter.

| Command | Description                                 |
|---------|---|
| > CTC2  | Sets time constant to 200 $\mu$ s (0.2 ms). |

## CTG Configure Tach Gain

Version A

**Type** Set-Up  
**Syntax** <a>CTGn  
**Units** % of torque gain  
**Range** 0 - 99  
**Default** Motor dependent  
**Response** \*TACH\_GAIN\_PERCENT=nn  
**See also** CTGM

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the tach gain of the servo loop. When you tune the drive using the CTG command, you are setting a percentage of the Configure Tach Gain Maximum (CTGM).

| Command | Description                                |
|---------|--|
| > CTG33 | Sets tach gain to 33% of the maximum value |

## CTGM Configure Tach Gain Maximum

Version A

**Type** Set-Up  
**Syntax** <a>CTGMn  
**Units** n = maximum torque gain  
**Range** 0 - 32767  
**Default** Motor dependent  
**Response** \*TACH\_GAIN\_MAXIMUM=nnnnn  
**See also** CTG

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the maximum tach gain for the servo loop. When you tune the drive, you must first set CTGM and then adjust the overall derivative gain parameter by increasing or decreasing the CTG value. CTGM is configured at the factory and typically does not need to be adjusted. Refer to Display Drive Information (DDI) command example.

| Command    | Description                     |
|------------|---------------------------------|
| > CTGM2000 | Sets maximum tach gain to 2,000 |
| > CTG33    | Sets tach gain to 33% of 2,000  |

## CVE Configure Velocity Error

Version A

**Type** Set-Up  
**Syntax** <a>CVEn  
**Units** n = rpm  
**Range** 0 - 7000  
**Default** Motor dependent  
**Response** \*VELOCITY\_ERROR\_LIMIT=nnnn\_RPM  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command specifies a value for the maximum velocity error. If the absolute value of velocity error exceeds the CVE value, the amplifier will be disabled. This value represents the absolute value of velocity error. CVE0 will disable the velocity error fault.

| Command  | Description                                    |
|----------|--|
| > CVE100 | Sets the maximum velocity error to +/- 100 rpm |

## CVF Configure Velocity Feed-Forward

Version A

**Type** Set-Up  
**Syntax** <a>CVFn  
**Units** % of maximum velocity feed-forward  
**Range** 0 - 99  
**Default** Motor dependent  
**Response** \*VELOCITY\_FEED-FORWARD\_PERCENT=nn  
**See also** CVFM

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the velocity gain for the velocity control loop. When you tune the drive using the CVF command, you are setting a percentage of the Configure Velocity Feed-Forward Maximum (CVFM).

| Command | Description   |
|---------|---|
| > CVF15 | Sets velocity feed-forward gain to 15% of the maximum value |

## CVFM Configure Velocity Feed-Forward Maximum

Version A

**Type** Set-Up  
**Syntax** <a>CVFMn  
**Units** n = maximum velocity feed-forward  
**Range** 0 - 32767  
**Default** Motor dependent  
**Response** \*VELOCITY\_FEED-FORWARD\_MAXIMUM=nnnn  
**See also** CVF

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the maximum velocity gain for the velocity control loop. When you tune the drive, you must first set CVFM and then adjust the overall derivative gain parameter by increasing or decreasing the CVF. CVFM is configured at the factory and typically does not need to be adjusted. Refer to the Display Drive Information (DDI) command example.

| Command    | Description  |
|------------|--|
| > CVFM1000 | Sets the maximum velocity feed-forward gain to 1,000 |
| > CVF15    | Sets velocity feed-forward gain to 15% of 1,000      |

## CVI Configure Velocity Integral

Version A

**Type** Set-Up  
**Syntax** <a>CVIn  
**Units** % of maximum velocity integral gain  
**Range** 0 - 99  
**Default** Motor dependent  
**Response** \*POSITION\_INTEGRAL\_PERCENT=nn  
**See also** CVIM

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the integral gain for the velocity control loop. When you tune the drive using the CVI command, you are setting a percentage of the Configure Velocity Integral Maximum (CVIM).

| Command | Description   |
|---------|---|
| > CVI5  | Set velocity integral gain to 5% of the maximum value |

## CIM Configure Velocity Integral Maximum

Version A

**Type** Set-Up  
**Syntax** <a>CVIMn  
**Units** n = maximum integral gain  
**Range** 0 - 32767  
**Default** Motor Dependent  
**Response** \*POSITION\_INTEGRAL\_MAXIMUM=nnnn  
**See also** CVI

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the maximum integral gain for the velocity control loop. When you tune the drive, you must first set CVIM and then adjust the overall derivative gain parameter by increasing or decreasing the CVI. CVIM is configured at the factory and typically does not need to be adjusted. Refer to the Display Drive Information (DDI) command example.

| Command   | Description                              |
|-----------|--|
| > CVIM500 | Sets maximum integral gain to 500        |
| > CVI5    | Sets velocity integral gain to 5% of 500 |

## CVP Configure Velocity Proportional

Version A

**Type** Set-Up  
**Syntax** <a>CVPn  
**Units** n = % of maximum velocity proportional gain  
**Range** 0 - 99  
**Default** Motor dependent  
**Response** \*POSITION\_PROPORTIONAL\_PERCENT=nn  
**See also** CVPM

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the proportional gain for the velocity control loop. When you tune the drive using the CVP command, you are setting a percentage of the Configure Velocity Proportional Maximum (CVPM).

| Command | Description   |
|---------|---|
| > CVP35 | Sets velocity proportional gain to 35% of the maximum value |

## CVPM Configure Velocity Proportional Maximum

Version A

**Type** Set-Up  
**Syntax** <a>CVPMn  
**Units** n = maximum velocity proportional gain  
**Range** 0 - 32767  
**Default** Motor dependent  
**Response** \*POSITION\_PROPORTIONAL\_MAXIMUM=nnnnn  
**See also** CVP

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command defines the maximum proportional gain for the velocity control loop. When you tune the drive, you must first set CVPM and then adjust the overall derivative gain parameter by increasing or decreasing the CVP. CVPM is configured at the factory and typically does not need to be adjusted. Refer to the Display Drive Information (DDI) command example.

| Command    | Description                                     |
|------------|---|
| > CVPM2500 | Sets maximum to 2,500                           |
| > CVP35    | Sets velocity proportional gain to 35% of 2,500 |

## CZM Configure Z Drive Mode

Version A

**Type** Set-Up  
**Syntax** <a>CZMn  
**Units** n = mode  
**Range** 1 - 3  
**Default** 1  
**Response** \*Z\_MODE=1...POSITION  
\*Z\_MODE=2...TORQUE  
\*Z\_MODE=3...VELOCITY

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

**See also** None

The CZM command defines the mode of the Z Drive controller:

- 1 = Position servo mode
- 2 = Torque mode (from analog input)
- 3 = Velocity mode (from analog input)

Changing the operating mode of the Z Drive with the CZM command will reload all of the default tuning parameters for that particular mode. These new parameters are automatically saved. Refer to **Modes of Operation** in Chapter 4 *Application Design* for a detailed description of these parameters.

| Command | Description                                |
|---------|--|
| > CZM1  | Defines the controller as a position servo |

## DCA Display Current Average

Version A

**Type** Status  
**Syntax** aDCA<n>  
**Units** n = amps  
**Range** Motor Dependent  
**Default** None  
**Response** \*AVERAGE\_CURRENT\_(AMPS)=nnn.nn  
**See also** DCP, DCI

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command reports the average current commanded to the motor in amperes. This number is calculated by averaging 256 samples of instantaneous current.

- aDCA1 Reports the average current only once.
- aDCA Reports the average current continuously until a character is sent.

| Command | Response                       |
|---------|--------------------------------|
| > 1DCA  | *AVERAGE_CURRENT_(AMPS)=012.45 |

## DCI Display Current Instantaneous

Version A

**Type** Status  
**Syntax** aDCI<a>  
**Units** n = Amps  
**Range** Motor Dependent  
**Default** None  
**Response** \*INSTANTANEOUS\_CURRENT\_(AMPS)=nnn.nn  
**See also** DCA, DCP

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command reports the instantaneous current commanded to the motor in amperes.

- aDCI1 Reports the instantaneous current only once.
- aDCI Reports the instantaneous current continuously until a character is sent.

| Command | Response                             |
|---------|--------------------------------------|
| > 1DCI  | *INSTANTANEOUS_CURRENT_(AMPS)=032.88 |

## DCP Display Current Peak

Version A

**Type** Status  
**Syntax** aDCP<a>  
**Units** n = Amps  
**Range** Motor Dependent  
**Default** None  
**Response** \*PEAK\_CURRENT\_(AMPS)=nnn.nn  
**See also** DCA, DCI

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command reports the largest instantaneous current commanded by the controller since the DCP command was issued.

- aDCP1 Reports the peak current only once.
- aDCP Reports the peak current continuously until a character is sent.
- aDCP0 Resets peak current hold then, reports the peak current continuously until a character is sent.

| Command | Response                   |
|---------|----------------------------|
| > 1DCP  | *PEAK_CURRENT_(AMPS)=36.42 |

## DDI Display Drive Information

Version A

**Type** Status  
**Syntax** aDDI  
**Units** None  
**Range** None  
**Default** None  
**Response** See Below  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command displays all tuning parameters and other drive parameters at one time. A sample response is provided below.

```
      PP   PI   PD   VP   VI   VF   TG
*PERCENT 50  10  00  20  00  50  60
*MAXIMUM 10000 400 32000 5000 00 32000 32000

*TIME_CONSTANT=00005(*100_microSeconds)
*AVE_CURRENT_LIMIT=020.00_AMPS
*PEAK_CURRENT_LIMIT=040.00_AMPS
*MOTOR_RESOLUTION=05000_STEPS
*RESOLVER_RESOLUTION=AUTO
*MOTOR_TYPE=Z640
*Z_MODE=1...[POSITION]
```

## DISP' Front Panel Display

Version A

**Type** Status  
**Syntax** <a>DISP'x  
**Units** x = characters  
**Range** up to 126 characters  
**Default** OK  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

The DISP' command is used to change the *home* front-panel display message. The default message is OK (fixed, non-scrolling). The display message can either be a fixed message of 4 characters or less, or a scrolling message of up to 126 characters.

A four character display message can be entered by typing > DISP'xxxx where xxxx will be the message. If a blank space is desired in the message, an underscore must be entered (a space is interpreted as an end of command delimiter).

A scrolling display message can be entered by typing > DISP'xxx...xxx where xxx...xxx will be the scrolling message. Four blank spaces will be appended to the message. The message will repeatedly scrolled when no error messages are present.

| Command           | Description                     |
|-------------------|---------------------------------|
| > DISP' #1        | Home panel display is set to #1 |
| > DISP'TOOL_SLIDE | Display will scroll TOOL_SLIDE  |

## DPA Display Position Actual

Version A

**Type** Status  
**Syntax** aDPA<n>  
**Units** n = steps  
**Range** +2,147,483,647 -2,147,483,689  
**Default** None  
**Response** \*ACTUAL\_POSITION\_(STEPS)=±nnnnnnnnnn  
**See also** DPE, DPS, CMR

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command displays the actual cumulative resolver position in motor steps. The value is a cumulative count based on the shaft position when the drive was enabled. This command is scaled by the Configure Motor Resolution (CMR) command (steps are in the user's resolution).

- aDPA1 Reports the actual position only once.
- aDPA Reports the actual position continuously until a character is sent.

| Command | Response                             |
|---------|--------------------------------------|
| > 1DPA  | *ACTUAL_POSITION_(STEPS)=+0000345092 |

## DPE Display Position Error

Version A

**Type** Status  
**Syntax** aDPE<n>  
**Units** n = steps  
**Range** +2,147,483,647 -2,147,483,689  
**Default** None  
**Response** \*POSITION\_ERROR\_(STEPS)=±nnnnnnnnnn  
**See also** DPA, DPS, CMR

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command reports the difference between the position setpoint and the actual position. This command is scaled by the Configure Motor Resolution (CMR) command (steps are in the user's resolution).

- aDPE1 Reports the actual position once without descriptive text.
- aDPE Reports the actual position continuously until a character is sent to the Z Drive.

| Command | Response                            |
|---------|-------------------------------------|
| > 1DPE  | *POSITION_ERROR_(STEPS)=+0000000012 |

## DPR Display Position Resolver

Version A

**Type** Status  
**Syntax** aDPR<n>  
**Units** n = resolver steps  
**Range** 0 - 65,535  
**Default** None  
**Response** \*RESOLVER\_POSITION=nnnnn  
**See also** CMR

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

DPR reports the resolver position. The resolver is a single-speed resolver; for one complete CW rotation of the motor shaft the resolver position will go from 0 to 65535 counts. CCW rotation will cause the resolver position to count backwards. This information is not scaled by the CMR command. Use this command to verify proper resolver connection.

- aDPR Continually reports the resolver position value until any key is pressed
- aDPR1 Report resolver position value 1 time only without descriptive text.

| Command | Response                 |
|---------|--------------------------|
| > 1DPR  | *RESOLVER_POSITION=63281 |

## DPS

Version A

**Type** Status  
**Syntax** aDPS<n>  
**Units** n = steps  
**Range** +2,147,483,647 -2,147,483,689  
**Default** None  
**Response** \*POSITION\_SETPOINT\_(STEPS)=±nnnnnnnnnn  
**See also** DPA, DPE

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command reports the absolute position setpoint. The position setpoint indicates the Z Drive's commanded position. This position setpoint is the total number of steps that the drive has received since the amplifier was enabled.

- aDPS Continually reports the setpoint position value until any key is pressed
- aDPS1 Reports position setpoint value 1 time only without descriptive text.

| Command | Response                               |
|---------|--|
| > 1DPS  | *POSITION_SETPOINT_(STEPS)=+0000538112 |

## DSP Display Servo Picture

Version A

**Type** Status  
**Syntax** aDSP  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** SPA, DPE, DPS, DPR, DVA, DVE, DVS

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command draws a simple picture of the Z Drive servo loop, labeling various nodes, and then repeatedly displays most servo variables. This command can be used to display DPA, DPE, DPS, DPR, DVA, DVE, and DVS information. The servo variables are sampled at different points in time, the numbers shown will not necessarily correlate exactly.

## DVA Display Velocity Actual

Version A

**Type** Status  
**Syntax** aDVA<n>  
**Units** n = rpm  
**Range** 0 - 8,000  
**Default** None  
**Response** \*ACTUAL\_VELOCITY\_(rpm)=±nnnnn  
**See also** DVS, DVE

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command reports the shaft velocity in rpm (revolutions per minute).

- aDVA Continuously reports the actual velocity until any key is pressed
- aDVA1 Report the actual velocity once, without descriptive text.

| Command | Response                      |
|---------|-------------------------------|
| > 1DVA  | *ACTUAL_VELOCITY_(rpm)=+05732 |

## DVE

Version A

**Type** Status  
**Syntax** aDVE<n>  
**Units** n = rpm  
**Range** 0 - 8,000  
**Default** None  
**Response** \*VELOCITY\_ERROR\_(rpm)-±nnnnn  
**See also** DVS, DVA

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command reports the difference between the velocity setpoint and the actual velocity.

- aDVE1 Reports the velocity error only once.
- aDVE Reports the velocity error continuously until a character is sent.

| Command | Response                     |
|---------|------------------------------|
| > 1DVE  | *VELOCITY_ERROR_(rpm)=+00003 |

## DVS Display Velocity Setpoint

Version A

**Type** Status  
**Syntax** aDVS<n>  
**Units** n = rpm  
**Range** 0 - 8,000  
**Default** None  
**Response** \*VELOCITY\_SETPOINT\_(rpm)-±nnnnn  
**See also** DVA, DVE

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command continuously reports the commanded shaft velocity setpoint in rpm (revolutions per minute).

- aDVS Continuously reports the velocity setpoint until any key is pressed.
- aDVS1 Report the velocity setpoint once, without descriptive text.

| Command | Response                        |
|---------|---------------------------------|
| > 1DVS  | *VELOCITY_SETPOINT_(rpm)=+03712 |

## E Enable Communications Interface

Version A

**Type** Communication  
**Syntax** <a>E  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** F

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

The Enable Communications Interface (E) command allows the drive to accept commands over the RS-232C interface. You can re-enable the communications interface with this command if you had previously disabled the interface with the F command. If several units are using the same communications interface, the E and F commands can help streamline programming.

| Command | Description                                   |
|---------|---|
| > F     | Disables all units on the RS-232C interface   |
| > 1E    | Enables Device 1                              |
| > 4E    | Enables Device 4                              |
| > CPP35 | Sets CPP value to 35% for device 1 and 4 only |

## F Disable Communications Interface

Version A

**Type** Communication  
**Syntax** <a>F  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** E

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

Use the Disable Communications Interface (F) command to program multiple units on a single interface. Units that are not intended to process global commands should receive device specific F commands. This allows you to program other units without specifying a device identifier on every command.

| Command | Description  |
|---------|--|
| > 1F    | Disables communications on Device 1                        |
| > 3F    | Disables communications on Device 3                        |
| > CCA15 | Sets CCA value to 15 on all units except devices #1 and #3 |

## FMCA Find Motor Commutation Angle

Version A

**Type** Set-Up  
**Syntax** aFMCA  
**Units** None  
**Range** None  
**Default** 0  
**Response** See Below  
**See also** CMTR

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

All Z Drive motors have aligned resolvers so no calculation of the commutation angle is required. However, the FMCA command will recalculate this commutation angle if necessary. FMCA may be used to guarantee that the stored commutation angle is correct.

FMCA rotates the motor under program control in the drive. *While it is rotating, the user has no control over the motor. Once you start this sequence of events, you will have to cut off AC power to stop the motor before the commutation procedure is completed.* The motor must be disconnected from the load when FMCA is executed to ensure proper commutation angle.

Once commutation is completed, this angle is automatically saved in non-volatile memory. For any given motor, this commutation procedure does not have to be repeated.

| Command | Description / Response                    |
|---------|---|
| > 1OFF  | Turns amplifier off                       |
| > 1FMCA | *COMMUTATION_OFFSET=00006...[000_DEGRESS] |

## ^H Backspace

Version A

**Type** Communication  
**Syntax** ^H  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

^H allows you to delete the last character that you entered. (^H indicates that the Ctrl key is held down when the H key is pressed.) ^H will not prevent execution of a command after the command delimiter has been entered. The drive will backspace one character in the command buffer, regardless of what appears on the terminal. On some terminals, the Ctrl and the left arrow keys produce the same character.

| Command    | Description        |
|------------|--------------------|
| > CCX^HP35 | CCP setting is 35A |

## HELP Help

Version A

**Type** Status  
**Syntax** aHELP  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command lists all of the Z Drive commands and their descriptions.

## OFF Off

Version A

**Type** Programming  
**Syntax** <a>OFF  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** ON

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command disables the amplifier, no current is commanded to the motor. When you issue an OFF command, the fault LED will be on to indicate that the drive is shut down. You must issue an ON command to re-energize the motor and clear the fault. OFF removes motor torque, allowing you to move the motor manually. *If OFF is issued during motor motion, the motor will freewheel.*

| Command | Description                       |
|---------|-----------------------------------|
| > OFF   | Powers down the motor (no torque) |

## ON

### On

Version A

**Type** Programming  
**Syntax** <a>ON  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** OFF

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command turns the amplifier back on from the off state. If you issue the **OFF** command to shut the drive down, issuing the **ON** command re-enables the current to the motor, restoring motor torque.

| Command | Description            |
|---------|------------------------|
| > ON    | Turns the amplifier on |

## OUT

### Real Time Output Control

Version A

**Type** Set-Up  
**Syntax** <a>OUTn  
**Units** None  
**Range** 0 - 3  
**Default** 0  
**Response** \*OUT=0...RTO\_LOW  
\*OUT=1...RTO\_HIGH  
\*OUT=2...TEMPERATURE\_PRE-FAULT  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command can activate (**OUT1**) or negate (**OUT0**) the differential RTO (real time output) line or indicate a temperature fault (**OUT2**).

- OUT0** = RTO Low, never saved
- OUT1** = RTO High, never saved
- OUT2** = Temperature pre-fault, automatically saved
- OUT3** = Over-voltage warning, automatically saved

The **OUT0**, **OUT1** commands are not savable. The RTO line can be used to get an advance notice, or a pre-fault, of a temperature fault by entering **OUT2**. The RTO line will be activated one minute (fixed) prior to the amplifier shutdown when a PCB or motor temperature fault occurs. The system does not provide a pre-fault indication for a heatsink temperature fault. **OUT3** will activate the RTO line whenever the over-voltage warning is active.

| Command | Description            |
|---------|------------------------|
| > OUT1  | Activates the RTO line |

## RFS

### Return to Factory Settings

Version A

**Type** Communication  
**Syntax** <a>RFS  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** SV

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

**RFS** returns the following setup parameters to their default values: **ANDB**, **ANV**, **CCA**, **CCP**, **CDB**, **CIP**, **CMV**, **CPD**, **CPDM**, **CPE**, **CPI**, **CPIM**, **CPP**, **CPPM**, **CRR**, **CTC**, **CTG**, **CTGM**, **CVE**, **CVF**, **CVFM**, **CVI**, **CVIM**, **CVP**, **CVPM**, **DISP**, and motor commutation information.

You cannot execute the **RFS** command if the drive is enabled. Use the **OFF** command to turn the drive off. The tuning parameters that are returned to factory defaults are *not* automatically saved. Issue a Save (**SV**) command to save the tuning parameters in non-volatile memory. Non-tuning parameters are automatically saved.

| Command | Description                                      |
|---------|--|
| > OFF   | Turns amplifier off                              |
| > RFS   | Set-up parameters are returned to default values |
| > ON    | Turns amplifier on                               |

## RSE Report Servo Errors

Version A

|          |           |
|----------|-----------|
| Type     | Status    |
| Syntax   | aRSE<n>   |
| Units    | None      |
| Range    | None      |
| Default  | None      |
| Response | See Below |
| See also | None      |

|                         |
|-------------------------|
| <b>Attributes</b>       |
| [ ] Buffered            |
| [ ] Device specific     |
| [ ] Saved independently |
| [ ] Saved in sequences  |

In addition to the front panel display, you can report error or warning conditions over RS-232C by using this command. Use **RSE** to troubleshoot the unit when a fault occurs. *Chapter 8 Troubleshooting & Maintenance* discusses all of these errors and offers troubleshooting help. The possible messages are:

```
*NO_ERRORS/WARNINGS
*DRIVE_WARNINGS:
    *Ø3_OVER_VOLTAGE
*DRIVE_ERRORS:
    *Ø4_OVER_VOLTAGE
    *17_INDEXER_SHUTDOWN
    *18_LOW_VOLTAGE
    *19_SHORT_CIRCUIT:_CYCLE_POWER
    *2Ø_POSITION_ERROR_EXCEEDED
    *21_ROLLING_AVE_CURRENT_FAULT
    *22_AVERAGE_CURRENT_LIMIT_EXCEEDED
    *23_DRIVE_ENABLE_NOT_ACTIVE
    *27_VELOCITY_ERROR_EXCEEDED
    *3Ø_ZRAM_FAILURE
    *55_POWER_SUPPLY_FAILURE
    *6Ø_COMMANDED_SHUTDOWN
    *61_INCOMING_INDEXER_PULSES
    *7Ø_RESOLVER_DISCONNECTED
    *77_RESOLVER_RESOLUTION_FAULT
    *91_HEATSINK_OVER_TEMPERATURE
    *92_MOTOR_OVER_TEMPERATURE
    *93_PCB_OVER_TEMPERATURE
```

**RSEØ** displays old errors; errors that have been cleared by turning the drive on (ON command or a reset). The microprocessor saves errors that disable the amplifier. Additional errors that occur after the amplifier is off will not be saved. Errors are saved prior to the microprocessor canceling the drive fault output on the Indexer Connector. If you want to remove power from the Z Drive when a drive fault occurs, use the drive fault output to ensure that the microprocessor has enough time to save the errors before power is lost. The fault output on the screw terminal I/O[2] connector is a hardware fault signal (hardware generated fault) that will be activated before the microprocessor saves errors.

| Command | Response                                      |
|---------|---|
| > 1RSE  | *DRIVE_ERRORS:<br>*2Ø_POSITION_ERROR_EXCEEDED |
| > ON    |   |
| > 1RSE  | *NO_ERRORS/WARNINGS                           |
| > 1RSEØ | *OLD_ERRORS:<br>*2Ø_POSITION_ERROR_EXCEEDED   |

## RV Revision Level

Version A

|          |                                 |
|----------|---------------------------------|
| Type     | Status                          |
| Syntax   | aRV                             |
| Units    | None                            |
| Range    | None                            |
| Default  | None                            |
| Response | *92-010672-01xx *92-010799-01xx |
| See also | None                            |

|                         |
|-------------------------|
| <b>Attributes</b>       |
| [ ] Buffered            |
| [ ] Device specific     |
| [ ] Saved independently |
| [ ] Saved in sequences  |

The Revision (**RV**) command reports the software part numbers of both Z Drive processors and their revision levels. The part numbers (92-010672-01 and 92-010799-01) identify the installed software. The suffixes (xx) identify the revision levels. Record this information, it is required if you consult Compumotor's Applications Department.

| Command | Response                      |
|---------|-------------------------------|
| > 1RV   | *92-010672-01A *92-010799-01A |

The software is identified by 92-010672-01 revision level A, and 92-010799-01 revision level A.

## SS Set-Up Status Report

Version A

**Type** Status  
**Syntax** aSS  
**Units** None  
**Range** None  
**Default** None  
**Response** See Below  
**See also** SSA, SSI, SSM, SSR, SST, SSU

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

Reports the status of the **SS** commands (**SSA**, **SSI**, **SSM**, **SSR**, and **SST**) settings.

| Command | Response   |
|---------|--|
| > 1SS   | *SSA=0...RS232_ECHO=ON<br>*SSI=0...INTERACTIVE_MODE=ON<br>*SSM=0...ACTIVE_DIR_INPUT=CW<br>*SSR=0...ANALOG_OUT=VELOCITY<br>*SST=0...ENABLE_INPUT=NORMAL<br>*SSU=1...WARNING_DISPLAY=OFF |

## SSA RS-232C Echo Control

Version A

**Type** Set-Up  
**Syntax** <a>SSAn  
**Units** n = mode  
**Range** 0, 1  
**Default** 0  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command turns the RS-232C echo (transmission by the drive of characters received from the remote device) on and off.

- SSA0 = Echo on
- SSA1 = Echo off

In the Echo On (**SSA0**) mode, characters that are received by the drive are echoed automatically. In the Echo Off (**SSA1**) mode, characters are not echoed from the drive. Use **SSA1** if you do not want the drive to echo. In a daisy chain, you must have the echo turned on to allow drives further down the chain to receive commands.

| Command | Description    |
|---------|----------------|
| > SSA1  | Turns echo off |

## SSI Interactive Mode Control

Version A

**Type** Set-Up  
**Syntax** <a>SSI n  
**Units** n = mode  
**Range** 0, 1  
**Default** 0  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command turns the RS-232C interactive mode on and off.

- SSI0 = Interactive mode on
- SSI1 = Interactive mode off

If the interactive mode is on (**SSI0**), the drive transmits a command prompt after each RS-232C command has been executed. The command prompt consists of a carriage return, line feed, a '>', and a space. If the last command was rejected, then a '?' character would be sent (instead of a '>'). '\*READY' will be sent each time the Z Drive is reset.

If the interactive mode is off (**SSI1**), then no prompt is sent. Use **SSI1** if you do not want to transmit a carriage return or line feed. Only device address 1 is capable of sending command prompts.

| Command | Description                  |
|---------|------------------------------|
| > SSI1  | Turns the command prompt off |

## SSM Direction Input Polarity Control

Version A

**Type** Set-Up  
**Syntax** <a>SSMn  
**Units** n = mode  
**Range** 0, 1  
**Default** 0  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

This command can be used to reverse the polarity of the direction input.

- SSM0** = Active Direction input is CW
- SSM1** = Active Direction input is CCW

Compumotor's standard interpretation is an active DIR input (DIR+ = 5V, DIR- = 0V) equals CW. With **SSM1**, you can reverse the polarity if desired.

| Command       | Description  |
|---------------|--|
| > <b>SSM0</b> | An active DIR input will cause incoming steps to be interpreted as a CW commanded position |

## SSR Analog Output Control

Version A

**Type** Set-Up  
**Syntax** <a>SSRn  
**Units** n = mode  
**Range** 0, 1  
**Default** 0  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

You can use **SSR** to monitor either velocity or torque at the monitor output on the Z Drive.

- SSR0** = Analog monitor output is velocity
- SSR1** = Analog monitor output is the absolute torque value

| Command       | Description  |
|---------------|--|
| > <b>SSR0</b> | The motor shaft velocity will be in an analog format at the monitor output |

## SST Enable Input Control

Version A

**Type** Set-Up  
**Syntax** <a>SSTn  
**Units** n = mode  
**Range** 0, 1  
**Default** 0  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

- SST0** Enable input is in *normal* mode, once disabled from this input the drive remains disabled until an **ON** command or a drive reset.
- SST1** Enable input is in *Shutdown* mode, once disabled from this input the drive can be re-enabled by replacing the jumper (see [Chapter 3 Installation](#) for detailed description of the Enable input). In this *shutdown* mode the Enable input behaves just like the Remote Power Shutdown input.

| Command       | Description                      |
|---------------|----------------------------------|
| > <b>SST1</b> | Enable input is in Shutdown mode |

## SSU Set Warning Display Mode

Version A

**Type** Set-Up  
**Syntax** <a>SSUn  
**Units** n = mode  
**Range** 0, 1  
**Default** 0  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

**SSU0** = Enables Warning Display mode  
**SSU1** = Disables Warning Display mode

When **SSU1** is entered the Z will not display warning messages. When **SSU0** is entered, the Z will display all pending warning messages.

## SV

## Save Tuning Parameters

Version A

**Type** Set-Up  
**Syntax** <a>SV  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

sv will save all current tuning parameters that have been defined (into battery backed RAM). The following parameters are saved in response to a sv command. Commands not listed here may be automatically saved when that command is entered. See the description of those individual commands: CPD, CPDM, CPI, CPIM, CPP, CPPM, CTC, CVD, CVDM, CVI, CVIM, CVP, CVPM.

| Command | Description                         |
|---------|-------------------------------------|
| > SV    | Response after successful save is:* |

## Z

## Reset

Version A

**Type** Programming  
**Syntax** <a>Z  
**Units** None  
**Range** None  
**Default** None  
**Response** None  
**See also** None

**Attributes**  
[ ] Buffered  
[ ] Device specific  
[ ] Saved independently  
[ ] Saved in sequences

The Reset (z) command is equivalent to cycling AC power to the Z Drive. This command returns all internal settings to their power-up values. *When the Z Drive is reset, the drive is busy for approximately 25 ms for system initialization (all commands are ignored).*

| Command | Description             |
|---------|-------------------------|
| > z     | Software reset of drive |